

Quick Start Guide



Warranty and Service

Register your purchase with Phaedrus Audio at www.phaedrus-audio/registration.htm

Service

If you experience a problem with a Phædrus Audio product, go to:

www.phaedrus-audio.com/contact.htm

Phædrus Audio's Warranty

Go here for details:

www.phaedrus-audio.com/phaedrus_t&cs.htm

Manual

Be sure to download a manual for your product: www.phaedrus-audio.com/downloads.htm


User Access & Servicing

Phædrus Audio equipment employs hazardous voltages for the high-tension supplies. THE USER SHOULD NOT ATTEMPT TO SERVICE THE UNIT.

External power supplies

Most Phædrus Audio's products are all powered by external power supplies. Only use power supplies from Phaedrus Audio. Note that the Resolve PSU and London Series PSUs are NOT COMPATIBLE.

Connections - London Series & Electronic Tubes



Input:

Unbalanced: 3 pin XLR Connector

Pin 1 - Ground

Pin 2 – (+) Signal

Pin 3 - Connect to Pin 1

Output:

Unbalanced: 3 pin XLR Connector

Pin 1 - Ground

Pin 2 - (+) Signal

Pin 3 - Connect to Pin 1*

*Leave o/c for PHILTER and PHUSION

Balanced: 3 pin XLR Connector

Pin 1 - Ground

Pin 2 - (+) Signal


Pin 3 - (-) Signal

Balanced: 3 pin XLR Connector

Pin 1 - Ground

Pin 2 - (+) Signal

Pin 3 - (-) Signal



scr

Standard panel

Send/ return (PHUSION):

Unbalanced: stereo 6.3mm stereo jack Tip – Send

Tip – Send Ring – Return

Sleeve - Ground

PHAMULUS link:

Unbalanced: Mono 3.5mm jack – jack

Tip – link potential Sleeve - Ground

